



A. 333-5060

32 oz. Coffee Pot

B. 333-5057

64 oz. Water Pitcher
W/O Ice Guard

C. 333-5061

64 oz. Coffee Pot

D. 333-5059

18 oz. Coffee Pot

E. 333-5050

10 oz. Creamer

F. 333-5058

10 oz. Coffee Pot

G. 333-5053

10 oz. Sugar Bowl



A. 333-7201

48 oz. Coffee Pot

B. 333-7200

48 oz. Water Pitcher

C. 333-7202

28 oz. Coffee Pot

D. 333-7205

18 oz. Coffee Pot

E. 333-7206

28 oz. Coffee Pot
W/French Handle

F. 333-7207

10 oz. Coffee Pot

G. 333-7203

10 oz. Creamer

H. 333-7204

10 oz. Sugar Bowl

I. 333-7208

5 oz. Creamer

J. 333-7209

5 oz. Sugar Bowl

K. 333-7210

10 oz. Coffee Pot
W/French Handle



A. 333-1141

64 oz. Water Pitcher

B. 333-1139

32 oz. Coffee Pot

C. 333-1140

64 oz. Coffee Pot

D. 333-1138

18 oz. Coffee Pot

E. 333-1133

10 oz. Sugar Bowl

F. 333-1136

10 oz. Creamer

G. 333-1137

10 oz. Coffee Pot

H. 333-1135

5 oz. Creamer

I. 333-1134

5 oz. Sugar Bowl



A. 333-2863

64 oz. Water Pitcher

B. 333-2861

32 oz. Coffee Pot

C. 333-2862

64 oz. Coffee Pot

D. 333-2868

18 oz. Creamer

E. 333-2859

10 oz. Coffee Pot

F. 333-2860

18 oz. Coffee Pot

G. 333-2864

5 oz. Creamer

H. 333-2865

5 oz. Sugar Bowl

I. 333-1510

10" x 7" Oval Tray

J. 333-2866

10 oz. Creamer

K. 333-2867

10 oz. Sugar Bowl

L. 333-2960

Sugar Pack Holder

M. 333-2869

2 oz. Creamer

N. 333-2870

2 oz. Sugar Bowl

O. 333-1509

7" x 5" Oval Tray